

BLU
DOT



LAPS OF
FUN!

LAP CASEGOODS




ASSEMBLY NOTES



1



PARTS & HARDWARE




LAP

DOOR ADJUSTMENT & CARE



Clean with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for wood furniture. Wipe completely dry with a soft cloth in the direction of the wood grain.

Clean powder-coated units with a soft cloth or sponge using a mild detergent, such as dish soap, and warm water. Wipe completely dry with a soft cloth.



DOOR ALIGNMENT

Hinges work in unison with one another, meaning if you adjust one hinge chances are you will have to adjust all the hinges. Think of it as a balancing act between the door and its hinges.

IF DOOR NEEDS ADJUSTMENT FROM TOP TO BOTTOM, ADJUST DOOR USING SCREW #3

IF DOOR NEEDS ADJUSTMENT FROM SIDE TO SIDE, ADJUST DOOR USING SCREW #1

IF DOOR NEEDS ADJUSTMENT FROM FRONT TO BACK, ADJUST DOOR USING SCREW #2

